

INSTALLATION MANUAL

EVOLUS



GB

Operator
for sliding
automatic doors



EVOLUS - GB - Rel.1.5 - 01/2010 - CD0500GB

EVOLUS

TABLE OF CONTENTS:

GENERAL SAFETY WARNINGS	page	3
MAINTENANCE PROGRAM		3
1 - TYPICAL PLANT		4
2 - AUTOMATED EQUIPMENT DESCRIPTION		4
3 - COVERING CASING		8
4 - ADJUSTMENT OF THE BELT TENSIONING		9
5 - POSITIONING THE MECHANICAL LIMIT SWITCH		9
6 - ANCHORING THE LEAVES TO THE CARRIAGES AND ADJUSTING THEM		10
7 - INSTALLATION MEASURES		11
8 - REFERENCE STANDARDS		14
9 - ELECTRONIC CONTROL UNIT		21
10 - ELECTRIC CONNECTION DESCRIPTION		22
11 - PRJ38 PHOTOCELLS		25
12 - BATTERY-OPERATED OPENING DEVICE EV-BAT1		26
13 - FUNCTIONAL TESTING "INITIAL SET-UP"		26
14 - S1 DIP-SWITCH FUNCTIONS		27
15 - S2 DIP-SWITCH FUNCTIONS		28
16 - CONTROL UNIT POTENTIOMETER ADJUSTMENT		29
17 - WORK PROGRAM SELECTION DEVICES		30
17a) - EV-MSEL MECHANICAL KEY SELECTOR		30
17b) - EV-DSEL DIGITAL PROGRAMMER		31
18 - "UR1" MODULE		39
19 - DESCRIPTION OF FUNCTIONS SELECTABLE FROM EV-DSEL DIGITAL PROGRAMMER (F01 to F40)		39
20 - DESCRIPTION OF POTENTIOMETERS ADJUSTABLE FROM EV-DSEL DIGITAL PROGRAMMER (P01 to P35)		43
21 - INTERLOCKING SYSTEM BETWEEN TWO AUTOMATIC DOORS		46
22 - DOOR CROSSING WARNING GONG		48
23 - SENSOR TEST		49
24 - MEANING OF BUZZER WARNING SIGNALS (BIPs)		49
25 - PROBLEMS, CAUSES AND REMEDIES		50
DECLARATION OF CONFORMITY		51

Thoroughly read this manual before starting installation.

Both the mechanical and the electric systems must be installed in compliance with the code of practice and with the regulations in force. Failure to comply with them may result in injuries or damages.

The person in charge of installing the product must be skilled and properly qualified; he must make sure that the structure to be automatised is stable and robust, and if necessary make the required structural changes.

He must also check that all areas involving any danger of crushing, conveying, shearing, etc are protected by means of electronic safety devices, safety freeboards or safety fences.

These devices must be installed in compliance with the regulations in force and with the code of practice, also taking into account the usage environment, the usage type and the product operation logic.

Forces generated by the whole system during operation must comply with the regulations in force; should it turn out to be impossible, involved areas must be protected by electronic safety devices.

Dangerous areas must be signalled in accordance with the provisions of the regulations in force.

Before connecting the product make sure that the mains features are compatible with the technical data indicated in this manual and that upstream of the system there are a suitable residual current device and a suitable overcurrent protection device.

Remember to cut off the power supply before opening the machine cover, when performing any maintenance or installation operation.

Electrostatic charges may damage electronic components on boards; use grounded antistatic bracelets if you must perform any operation on electronic boards.

Don't insert your hands or other parts of your body into moving components like belts, pulleys, carriages, etc...

Product maintenance is essential for system operation and safety;

The periodical check of the efficiency of all parts should be carried out every 6 months.

The manufacturer accepts no responsibility for incorrect product installation and usage, as well as for any damages arising from changes to the system made without his prior consent.

Only genuine spare parts must be used for product component replacement and repair.

The manufacturer is not responsible for the construction of the fixtures to be automated, nor for any damages arising from failure to observe the code of practice in fixture construction.

The IP22 protection degree requires that automated equipment is installed only on the inner side of buildings.

The manufacturer accepts no responsibility for any damages caused by outdoor installation without suitable protection measures.

Before installing the product always check its integrity.

This product cannot be installed in explosive environment and atmosphere, or in the presence of flammable gases or fumes.

At the end of its life this product must be disposed of in accordance with the regulations in force.

Keep product and packaging materials out of children's reach, as they might be a source of danger.

Do not stay within the range of the door and do not impede the door movement voluntarily.

Do not let the children stay or play within the range of the door.

MAINTENANCE PROGRAM

Every 6 months:

Warning! Before performing any operation on the automated equipment cut off the main power supply.

- Check that all screws are tight.
- Check the belt's tension.
- Clean the carriage sliding rail and the ground sliding guide.
- Check that carriages and leaves are properly aligned and that the door's final ledge is in correct position.
- Check that the electric lock - if any - is properly fastened and that the mechanical release device operates properly.
- Check connections and electric cables
- Check leaf stability and make sure that they move smoothly and frictionless along the whole stroke.
- Check that motion speeds, involved forces and installed safety devices are working appropriately.
- Clean sensors and check that presence detectors activate properly.


Warning! Any damaged or worn system component must be replaced.

Make use only of original spare parts; for this purpose check Label price list.


1 - TYPICAL PLANT

- ①a INTERNAL RADAR FOR OPENING
- ①b EXTERNAL RADAR FOR OPENING
- ② START BUTTON
- ③ PROGRAM SELECTOR
- ④ CLOSING SAFETY CELLS PRJ38 (FT = transmitting photocell, FR = receiving photocell)
- ⑤ SAFETY SENSORS FOR OPENING
- ⑥ KEY SELECTOR FOR EMERGENCY OPENING
- ⑦ EVOLUS AUTOMATED EQUIPMENT

OUTER SIDE



INNER SIDE





Notes: The grey part identifies the radar and sensor detection area. For each device the picture indicates the number of cables and the relevant section in millimetres.

2 - AUTOMATED EQUIPMENT DESCRIPTION

2.1 - TECHNICAL SPECIFICATIONS


MODEL	EVOLUS-90/2	EVOLUS-90/1	EVOLUS-130/2	EVOLUS-130/1
Power supply	115/230V ac +/- 10% , 50-60Hz			
Power	80W		130W	
Maximum weight of door wings	90 Kg	130 Kg	150 Kg	200 Kg
Electric motor	40Vdc with encoder			
Opening speed	Max. 70 cm/s (per leaf)			
Closing speed	Max. 60 cm/s (per leaf)			
Pause time	Max. 20 sec.			
Working temperature	-20° C ÷ +50°C			
Degree of protection	IP22			
Power supply of external accessories	13 Vdc			
Transom dimensions (H x P.)	120 x 150 mm			
Transom length	max 6500 mm			

2.2 - PART DESCRIPTION




2.3 - COMPONENT ARRANGEMENT


DOUBLE DOOR LEAF WITHOUT ELECTRIC LOCK





SINGLE LEAF RH WITHOUT ELECTRIC LOCK



SINGLE LEAF LH WITHOUT ELECTRIC LOCK





DOUBLE DOOR LEAF WITH ELECTRIC LOCK





LT BEAM LENGTH $LT=2PL-B+2S+24$	PL FREE PASSAGE $PL=(LT+B)/2-S-6$	LM LEAF WIDTH $LM=(LT-B)/4+S/2-6$	F IDLE PULLEY T*3/4+75	M MOTOR 400mm	C CONTROL UNIT 345mm	E ELECTRIC LOCK T/2
------------------------------------	--------------------------------------	--------------------------------------	---------------------------	------------------	-------------------------	------------------------

SINGLE LEAF RH WITH ELECTRIC LOCK



LT BEAM LENGTH $LT=2PL-B+S+24$	PL FREE PASSAGE $PL=(LT+B-S)/2-12$	LM LEAF WIDTH $LM=(LT-B+S)/2-12$	F IDLE PULLEY LT-212	M MOTOR LT-LM-467	C CONTROL UNIT LT-LM-522	E ELECTRIC LOCK LT-97
-----------------------------------	---------------------------------------	-------------------------------------	-------------------------	----------------------	-----------------------------	--------------------------



SINGLE LEAF LH WITH ELECTRIC LOCK



LT BEAM LENGTH $LT=2PL-B+S+24$	PL FREE PASSAGE $PL=(LT+B-S)/2-12$	LM LEAF WIDTH $LM=(LT-B+S)/2-12$	F IDLE PULLEY LT-87	M MOTOR LT-LM-342	C CONTROL UNIT LT-LM-397	E ELECTRIC LOCK 97
-----------------------------------	---------------------------------------	-------------------------------------	------------------------	----------------------	-----------------------------	-----------------------

3 - COVERING CASING

The casing of the EVOLUS automated equipment features two support links (A) specially designed to ensure that it remains stable in the opening position.




To fully remove the casing from the automated equipment press the end section of the pins (B) located on the support links and extract them by pulling them from the opposite end (Fig. 1)

Manually support the casing before extracting the pin.

In the lower section of the casing there is a compensating profile allowing to close the gap between the fixture and the casing, thus improving the automated equipment appearance.

To adjust the compensating profile depth you must detach the casing from the automated equipment and put it on a flat surface FIG. 3.

Arrange the compensating profile as shown in the figure and fasten it to the casing by means of the special clips.




Choose the optimum adjustment depth for the compensating profile referring to Fig. 4 then fasten each plastic clip by first inserting the clip teeth into the compensating profile grooves and then pushing the upper section of the clip forward until it connects to the casing.

Put the casing back in place on the automated equipment by reinstalling the support links with the special pins, then close the casing over the automated equipment hooking the upper section to the transom FIG. 5.



Fasten the casing by means of the screws located on side panels FIG. 6.




If the beam is flush with the wall you can fasten the casing frontally, by drilling a hole at the front seat on the side panel and fastening the casing by means of the special EV-KFCF Kit (optional) FIG. 7.



4 - ADJUSTMENT OF THE BELT TENSIONING

To adjust belt tensioning slightly loosen the A screw of the idle pulley, then screw in (to increase belt tensioning) or unscrew (to decrease belt tensioning) the hexagonal screw B. After achieving the optimum driving belt tension fully tighten screw A.




5 - POSITIONING THE MECHANICAL LIMIT SWITCH

The mechanical limit switch must be adjusted so that both during opening and closing it stops the carriage stroke before the mobile leaf crashes against any other component.


It is also used by the electronic control unit to acquire the leaf limit points.

When adjusting the opening mechanical limit switch take into account that except for the set-up manoeuvre and for the first manoeuvre after a power failure, at the end of the opening the movable leaf stops about 5 mm before coming into contact with the limit switch.



To adjust the limit switch loosen the 2 fastening screws, move the limit switch to the desired position, then fully tighten the 2 screws again.




6 - ANCHORING THE LEAVES TO THE CARRIAGES AND ADJUSTING THEM



- Undo the two front screws "A" of every carriage and remove the movable part "C".
- Fasten the movable part "C" you removed to the fixture at the distance indicated in figure 11 if no electric lock is installed or in figure 12 if the electric lock is installed.
- Now hang the leaf to the automated equipment matching the two carriage parts, then screw the "A" screws into their seats without tightening them.
- Adjust the height of the leaf by means of the control screw "B" and fully tighten the two "A" screws.
- Adjust the leaf horizontally by means of the eyelets "E" provided in the movable part of the carriage.
- To ensure that the automated equipment works properly it is important that the mobile leaf is perpendicular to the transom.
- Adjust the height of the opposing wheel by operating the adjustment screw (D) so that the wheel skims the top inner part of the transom, but without exerting any pressure.
- Then manually move the leaf until it reaches the end of stroke and check that there are no frictions at any point; otherwise adjust the opposing wheel position again.





The transom must be fastened to a flat surface solid enough to bear the weight of the leaves to be used. If the wall or the support do not meet these characteristics you will have to provide for a suitable tubular element, as the transom is not self-bearing.


Fasten the transom by means of M6 steel or equivalent anchors.

The fastening points must be distributed alternately between the reference lines on the beam (L1 and L2) every 600mm.


The figure shows the fastening dimensions.

When drilling the beam and the wall take care not to damage the sliding rail (B1) as that would affect the operation and the noiselessness of the automated equipment.


After fastening the beam thoroughly clean the sliding area from any drilling scraps.



SECTION WITH COMMERCIAL PROFILES



SECTION WITH POLISHED EDGE ATTACHMENT




DIMENSIONAL TABLE FOR EVOLUS 90 AND 150 OPERATORS

LEGEND:


- PL = FREE PASSAGE
- LT = AUTOMATION LENGTH
- LM = LEAF WIDTH
- H = PASSAGE OPENING HEIGHT

1 MOBILE LEAF			2 MOBILE LEAVES		
Dimensioning mm			Dimensioning mm		
LT= automation length $LT=2PL-B+S+24$	LM= leaf S= overlapped part B=ledge with S=50 B=10 $LM= \frac{LT-B+S}{2} - 12$	PL= nominal passage opening $PL= \frac{LT+B-S}{2} - 12$	LT= automation length $LT=2PL-B+2S+24$	LM= leaf S= overlapped part B=ledge with S=50 B=10 $LM= \frac{LT-B}{4} + \frac{S}{2} - 6$	PL= nominal passage opening $PL= \frac{LT+B}{2} - S - 6$
2000	1008	968	2000	516.5	949
2500	1258	1218	2500	641.5	1199
3000	1508	1468	3000	766.5	1449
3500	1758	1718	3500	891.5	1699
4000	2008	1968	4000	1016.5	1949
4500	2258	2218	4500	1141.5	2199
5000	2508	2468	5000	1266.5	2449
5500	2758	2718	5500	1391.5	2699
6000	3008	2968	6000	1516.5	2949
6500	3258	3218	6500	1641.5	3199


Check the presence of the clearance distances indicated by the figures.




Clearance distances for head protection.



Clearance distances for body protection.



Clearance distances for finger protection.



Clearance distances for finger protection.

8 - ELECTRIC LOCK

1) GENERAL DESCRIPTION

The EVOLUS automation electric lock is available in 3 models, which are differentiated by their behaviour during a power failure.



a) FAIL SAFE “EV-EBFSA”

In the case of a power failure, both network voltage as well as emergency battery power, the electric lock will free the leaves, which can then be moved manually.



b) FAIL SECURE “EV-EBFSE”

In the case of a power failure, both network voltage as well as emergency battery power, the electric lock will keep the leaves blocked.



c) BISTABLE “EBBIS”

In the case of a power failure, both network voltage as well as emergency battery power, the electric lock will remain in its current position.

Therefore, the leaves are free if the electric lock was not activated, or will remain blocked if the electric lock was activated.



2) POSITIONING and ELECTRIC CONNECTION



The dimensions for fastening the electric lock on the automation are specified in paragraph 2.3.

The electric lock is fastened to the automation by 2 M6 X 10 screws on M6 nuts, which are located in the special lower slot in the crosspiece.

The sliding carriages must be regulated so that when the leaf is in the closed position, the electric lock lever can hook to the carriage bracket and keep the leaves blocked.



The electric lock kit includes a power supply cable. This cable has two wires on one end that are connected to the electric lock solenoid valve wires with the specific terminals. The other end of the cable has a connection that is inserted in the LOCK1 connector on the Evolus operator electronic control unit.

If the bistable electric lock EV-EBBIS is installed, there will be a second power cable. One end of it must be connected to the secondary solenoid valve cables (LOCK2) of the electric lock and the other end must be connected to the LOCK 2 output on the electronic control unit where the connector is located.

3) MANUAL RELEASE



The Fail Secure EV-EBFSE and Bistable EV-EBBIS models are equipped with the EV-EBSMA manual release system that is used to release the electric lock in the case of a power failure and therefore move the leaves freely.

3a) RIGHT SIDE FASTENING

To install the manual release, it is advisable to position the release knob to the right of the automation.

Ⓐ



In this case, the bend pipe must be inserted inside the plastic base.

Ⓑ




Insert the steel cable inside the bend pipe as shown in the figure.

Ⓒ



...and inside the 3 plastic release components as shown in the figure, being careful to place the compression spring between the second and third plastic release components.

Ⓓ



Ⓔ



Fasten the base of the release knob to the side panel using 2 self-threading screws, making the bend pipe enter the hole made in the side panel.

Apply the adhesive label as shown in the figure, taking the four black bands on the label as a reference, which must be positioned in correspondence of the 4 cardinal points.

Insert the steel cable terminal into the release knob as shown in the figure and fasten the knob to the base with the special screw.

Ⓕ



Apply the screw cover label on the fixing screw.

By moving the release knob to the NOT RELEASED position, only the orange part of the label must be seen with the drawn black arrows.

Ⓖ




At this point, insert the plastic release components inside the specific slot made in the upper part of the crosspiece and check that they can slide freely in their housing without going out.

Ⓕ



Fasten the first plastic release component near the right side panel with 2 of the self-threading screws in the kit, which will catch in the narrow slot on the crosspiece.


Ⓖ



Position the second and third plastic release components as shown in the figure, making sure that the stroke of the third component is sufficient to activate the lever on the electric lock. Fasten the second component into position with self-threading screws.

Position the third component and fasten it into position using the terminal that acts as a clamp on the steel cable.

(L)



Turn the release knob to check system operation; turning the knob clockwise to a released position, the electric lock must free the leaves and when returning the knob to the blocked position, the electric lock must block the leaves again.

Cut the steel cable to remove the excess.

3b) LEFT SIDE FASTENING

(M)



If the release knob cannot be installed on the right side of the automation (recommended), it can be installed on the left side.

In this case, the adjustment register must be fastened on the base of the release knob.

(N)



Insert the steel cable inside the adjustment register and the sheath...

(O)



...and fasten the base of the release knob to the side panel using 2 self-threading screws.

(P)



Insert the plastic release components as shown in the figure, considering that 4 plastic components are necessary to install the manual release on the left side.

Q




A 250mm sheath must be placed between the second and third plastic release components and the compression spring between the third and the fourth.

R



At this point, insert the plastic release components inside the specific slot made in the upper part of the crosspiece and check that they can slide freely in their housing without going out.

S



In order to keep the sheath in position, it is recommended to insert it in one of the automation's fairleads.


T




Turn the release knob to check system operation; turning the knob clockwise to a "released" position, the electric lock must free the leaves and when returning the knob to the blocked position, the electric lock must block the leaves again.

Cut the steel cable to remove the excess.

4) INSTALLATION OF THE MANUAL RELEASE ON THE WALL




Identify the fastening point on the wall, considering that the standard cable sheath is 50 cm long.




Drill the wall and fasten the base of the release mechanism using the fastening screws.

Position the adhesive label as shown in the figure, taking the four black bands on the label as a reference, which must be positioned in correspondence of the 4 cardinal points. Insert the adjustment register using 2 nuts, one in the plastic slot and the other outside of it.



Pass the release cable in the slit in the base and then inside the adjustment register as shown in the figure. Then position the cable terminal on the release knob cable block (see figure).



Now, insert the release knob on the base of the mechanism, being careful to keep the cable terminal in the seat of the cable block and the knob in the correct position. When inserting the knob, the cable terminal must be in the position just beyond the lower fastening screw, in a clockwise direction.



Once the knob is inserted, fasten the closing screw, insert the sheath and turn the knob to the UNRELEASED position. In this position, only the orange part of the label must be seen with the drawn black arrows.

Make sure that the system is operating by turning the knob clockwise and keeping the cable taut with your hand.

WARNING!
THE KNOB TURNS MAX 45-50 DEGREES AND AT THE END, THERE ARE CLICKS IN ORDER TO MAINTAIN THE POSITION AFTER THE RELEASE.

Apply the provided screw cover label as shown in the figure and return the knob to the UNRELEASED position.

Now, bring the cable inside the beam. This can be done in two ways:

1) By means of the specific slit in the side plastic cap (Fig.A).


2) From the lower part of the beam using a plastic release component when there is no space on the sides of the automation (Fig.B).



Now, follow the steps described in point D) and from point G) to point L) in order to complete the installation of the electric lock if the steel cable enters from the left side of the automation.

If the steel cable enters from the left side of the automation, follow the steps from point P) to point T).

To finish, check that when the release is activated, the electric lock can free the leaves.



CONTROL AND DISPLAY COMPONENTS

LEDS

- DL1 (40V)** = presence of 40V voltage at the switching power supply.
- DL2 (13V)** = presence of the 13V output voltage at terminals 17-18.
- DL3 (E1) - DL4 (E2)** = they display the signals coming from the encoder sensor.
- DL5 (WD)** = it displays the proper operation of the main micro-controller MP1 by blinking very fast; if the led is off or it blinks slowly it indicates an electronic board fault.
- DL6 (F1)** = it displays the status of photocell 1 mod. PRJ38.
- DL7 (F2)** = it displays the status of photocell 2 mod. PRJ38.
- DL8 (F3)** = it displays the status of photocell 3 mod. PRJ38.

- Dip switch S1-S2** = they select the work functions of the control unit.
- TM1 to TM6 potentiometers** = calibration of the control unit work parameters.
- Buzzer** = Buzzer.
- MP1** = micro-controller with software version indication label.
- PS1** = START button. It performs door opening.
- PS2** = SET-UP button. It performs the initial set-up of the control unit.

10 - ELECTRIC CONNECTION DESCRIPTION

WARNING!!

On the plastic side panels of the EVOLUS operator control unit (part 1 in figure in para. 2.2) there is a hole that must be broken open, through which the electric cables must be inserted.

Along the upper part of the aluminium crosspiece, there are various fairleads (part 8 in the figure in para. 2.2) inside of which the cables should be run.

The installer must prepare suitable fairleads on the side panel of the operator control unit for the passage of the cables and ensure wire stability inside the operator control unit prior to the start-up of the automatic door, in order to prevent any contact between the electric cables and the moving parts of the automatism.

TERMINAL BOARD 1 (F-N-GROUND)

230Vac 50-60Hz mains supply;
phase at terminal F, neutral at terminal N, ground at terminal \perp


Ground the operator by connecting the ground cable from the line to the Faston connector on the aluminum beam, connect the second ground Faston on the beam to the ground terminal on the electronic control unit.

The line is protected by 5A fuse F1.

On the power supply network foresee an omni-polar switch/selector with contact opening distance at least of 3 mm.

The power supply line must be protected against short circuit and dispersion to ground.


Separate the 230Vac power supply line from the very-low voltage line control unit relative to control and safety accessories.



TERMINAL BOARD M2 (Voltage selection)

If the mains voltage is 230Vac **don't wire** the terminal.

Only if the mains voltage is 115Vac connect the terminal poles to each other.



TERMINAL BOARD M3 (Power supply of external accessories)


13Vdc output for power supply to accessories (radar, photocells, sensors). Max. load 400mA.

17= Positive terminal +13V.

18= Negative terminal 0.

The presence of the output voltage is displayed by the DL2 led.

16= TEST terminal for safety sensors prearranged with test function. (The J12 jumper on the control unit allows to select whether the test signal must be positive P or negative N. The choice depends on the type of sensor in use).



TERMINAL BOARD M4 (Inputs 11, 12, 13, 14, 15)


11 = Input COMMON.

12 = auxiliary AUX 1. N.O. contact serving for different functions depending on the configuration set on the control board:

- a) Using the mechanical key selector for the choice of the door work program (dip 6 of S1 ON) connect terminal 12 to terminal 3 of the mechanical selector.
- b) It can be used to set the "Night lock" (closed contact) or two-way traffic (open contact) function if operation with digital programmer (dip 6 of S1 OFF) is selected. In this case the door can be managed by a simple switch allowing to pass from the day function to the night lock, without using the digital programmer.

In the digital programmer is present, the activation of the AUX 1 input causes the door to close and the Night lock function to activate, by-passing the digital programmer setting.

- c) If INTERLOCK operation is activated between two Label automatic doors (dip 22 ON, only selectable from the digital programmer menu), the activation of the AUX1 input by-passes the interlock function (see the "Interlock system" paragraph).



13 = input of the Safety side sensor for opening; N.C. contact.

The door opens at low speed if it detects an obstacle during opening (if dip 8 of S2 is OFF).

The door stops if it detects an obstacle during opening (if dip 8 of S2 is ON).

14 = STOP or INTERLOCK input. N.C. contact that can be used for two different purposes depending on the configuration set on the control unit:

- a) Stop command to stop door motion.
- b) Interlock signal detection, preventing door opening when the interlock function is set (dip 22 ON, only selectable from the digital programmer menu).
- c) Connection of a smoke detector to force the door to close in case of smoke detection, when the F31 function is ON, function specific for fire doors.

15 = AUX 2 auxiliary. N.O. contact.

Using the EV-MSEL mechanical key selector for the choice of the door work program (dip 6 of S1 ON) connect terminal 15 to terminal 4 of the mechanical selector.

TERMINAL BOARD M5 (Inputs 5, 6, 7, 8, 9, 10)

5 = EMERGENCY input. N.C. contact.

Activation always causes the door to open, under any condition.

6 = input of the safety side PHOTOCELL for closing; N.C. contact.

If during closing it detects the presence of an obstacle the door stops and reopens.

If during pause it detects the presence of an obstacle the door remains open.

7 = Input COMMON.

8 = INTERNAL RADAR input. N.O. contact.

Activation causes the door to open when the day functions are on, except when the program selector is set to incoming only or to night lock.


9 = EXTERNAL RADAR input. N.O. contact.

Activation causes the door to open when the day functions are on, except when the program selector is set to outgoing only or to night lock.

10 = START input. N.O. contact.

Activation causes the door to open when the day functions are on, while it doesn't open when the program selector is set to incoming only or to night lock.

When the "WINTER OPENING" work program is selected the START command fully opens the door anyway.



· TERMINAL BOARD M6 (Receiving photocells PRJ38)


FR1 = PRJ38 1 receiving capsule signal (brown cable).

FR2 = PRJ38 2 receiving capsule signal (brown cable).

FR3 = PRJ38 3 receiving capsule signal (brown cable).

VCC = power supply positive for all receiving capsules (blue cables).

GND = power supply negative for all receiving capsules (black cables).




· TERMINAL BOARD M7 (Transmitting photocells PRJ38)

+FT = power supply positive for all transmitting capsules (blue cables).

FT1 = PRJ38 1 transmitting capsule signal (brown cable).

FT2 = PRJ38 2 transmitting capsule signal (brown cable).

FT3 = PRJ38 3 transmitting capsule signal (brown cable).



· TERMINAL BOARD M8 (Digital programmer)


1 = 13V power supply positive to be connected to the relevant + of the digital programmer.

2 = A communication signal to be connected to the relevant A of the digital programmer.

3 = B communication signal to be connected to the relevant B of the digital programmer.

4 = GND power supply negative to be connected to the relevant - of the digital programmer.

Connect the digital programmer to the control unit through a 4-pole cable with a diameter of 0.5 mm.



- **CONNECTOR J1:** Battery charger board connection.
- **CONNECTOR J3:** Encoder wiring connection.
- **CONNECTOR J4:** Motor wiring connection.
- **CONNECTOR J5:** Electric lock 1 wiring connection (LOCK1).
- **CONNECTOR J6:** Electric lock 2 wiring connection (LOCK2).
- **CONNECTOR J7:** Optional UR1 module connection (OUT3).
- **CONNECTOR J8:** Optional UR1 module connection (OUT4).

Distinguishing between transmitting and receiving capsules


Each pair of PRJ38 Label photocells consists of a transmitting and a receiving capsule.

Transmitting capsules have a rounded shape, while the receiving ones have a squared shape in the connection cable exit section. The transmitting capsule, besides, is equipped with a 2-wire cable bearing the PRJ38-TX mark, while the receiving capsule has a 3-wire cable bearing the PRJ38-RX mark.


Drill an 11.5 mm hole to fasten the capsules into the fixture.

To avoid any interference due to exposure to direct sunlight we recommend that you install the receiving capsules on the side that is best protected against sun rays.

For the electric connection of the photocells to the control unit please refer to the paragraph "Electric connection description".



RECEIVING



TRANSMITTING

Selecting the number of installed photocell pairs

The electronic control unit of the Evolus automatic door can manage up to 3 photocell pairs, two of which (FT1/FR1 and FT2/FR2) as safety device for closing, while the third pair (FT3/FR3) can be used in three different ways: as leave breaking sensor if a breakout device is used, as a safety device for closing, or as an opening control. You need to select the pairs of photocells used in the system on the electronic control unit; Table 1 indicates the selection method.

TABLE 1

EVOLUS control unit DIP switch S2

FT1/FR1 photocell management: F1 display led	
DIP 1 OFF	Photocell FT1/FR1 not installed
DIP 1 ON	Photocell FT1/FR1 installed

FT2/FR2 photocell management: F2 display led	
DIP 2 OFF	Photocell FT2/FR2 not installed
DIP 2 ON	Photocell FT2/FR2 installed


FT1/FR1 photocell management: F3 display led		
DIP 3	DIP 4	
OFF	OFF	Photocell FT3/FR3 not installed
ON	OFF	Photocell FT3/FR3 installed as leave breaking sensor
OFF	ON	Photocell FT3/FR3 installed as safety device for closing
ON	ON	Photocell FT3/FR3 installed as opening control

Photocell operation

If the PRJ38 photocells are not installed leds F1, F2, F3 on the electronic control unit are highlighted.

To ensure proper operation the photocell pairs must be perfectly aligned and at the same height; that is, the FT1 transmitter must be aligned with the FR1 transmitter, and the same applies to the other pairs. The maximum distance that can be covered by a photocell pair is of 6 metres.

- Calibrate the TM6 potentiometer on the electronic board so as to cover the distance between capsules. The led associated with the photocell pair will switch from high to low lighting, indicating that the photocell is working properly.
- If the infrared beam of the photocells is interrupted the relevant led switches from low to high lighting.



Signalling of any operation faults

- The PRJ38 photocells are constantly monitored by the control unit software, to guarantee a high safety level. If an error is detected during self-testing, the control unit emits one, two or three beeps, depending on the photocell pair that generated the malfunction. To avoid locking the open automated device and guarantee safety during closing, the door closes at reduced speed until normal photocell operation is restored.
- If during normal door operation the photocell beam is interrupted by an obstacle, the door stays open and the photocell control led stays steadily on.

12 - BATTERY-OPERATED OPENING DEVICE EV-BAT1

Insert the battery charger board into connector J1 located on the control unit (see the figure to the side).


Connect the battery paying attention to its polarity (red cable +, black cable -), referring to the two male festoons on the control unit.

The battery charger board self-checks the battery charge level and displays a green and a red led.

The green led blinks while the battery is being charged, while it stays steadily on at the end of the charging stage and during holding.

The red led blinks if the battery is low or damaged with and without mains voltage, while it is steadily on in case of charged battery without mains voltage.

If both leds are on that means that the battery is disconnected.



- Periodically check battery efficiency
- To allow recharging batteries must always be connected to the electronic control unit
- The equipment must be disconnected from the power supply when removing the batteries
- In case of replacement, always use genuine batteries (NiMH, 18V, 700mAh).
- In the case of replacement, do not use non-rechargeable batteries.
- Replacement must be performed by qualified personnel.
- Remove batteries from the equipment before its disposal.
- Batteries contain polluting substances; therefore they must be disposed of in accordance with the provisions of local regulations.

13 - FUNCTIONAL TESTING "INITIAL SET-UP"

After performing the mechanical installation of the automatic door and the electrical connections to the electronic control unit, you can start up the automated equipment.

• Preliminary checks

- check the cleanliness of the sliding rail and of the ground guide;
- check the belt's tension;
- check that leaves are properly aligned and fastened to chariots;
- check that the position of the limit switch mechanical stop is correct;
- check that leaves move smoothly and frictionless;
- check proper operation of the electric lock, if installed, and of the relevant manual release.

• Initial SET-UP

The SET-UP procedure is a mandatory operation allowing the control unit to store leaf stroke and weight, to optimise door operation. Strictly follow the next steps.

- For the EVOLUS model:** if the automated equipment is *single-leaf with rightward opening* set dip 5 of S1 to ON; if the automated equipment is *double-leaf or single-leaf with leftward opening* set dip 5 of S1 to OFF.
For the EVOLUS-T model: if the automated equipment has *two mobile leaves with leftward opening* set dip 5 of S1 to ON, if the automated equipment has *4 mobile leaves or two mobile leaves with rightward opening* set dip 5 of S1 to OFF.
- If the automation model is EVOLUS 90 or EVOLUS-T200 set dip 9 on S2 to OFF, if the automation is EVOLUS 150 or EVOLUS-T300 set dip 9 on S2 to ON.
- If the FAIL SAFE model electric lock is installed set dip 9 of S1 to ON; if the FAIL SECURE model electric lock is used, instead, or if no electric lock is installed, set 9 of S1 to OFF.
- If the EV-DSEL digital programmer is installed, set dip6 of S1 to OFF, if the EV-MSEL mechanical key selector is installed, set dip6 of S1 to ON.
- If the LABEL PRJ38 photocells are installed, set the dips 1 - 4 of S2 according to the number of photocells that are present (see paragraph 15)
- Check that the TM4 potentiometer (thrust power) is set to a value between middle range and maximum.
- Supply power to the electronic control unit, that will emit an initial beep and a short series of close beeps to indicate that there is no set-up in its internal memory.
- Press and hold the **PS2** set-up button as long as the control unit buzzer emits the fast beeps, then release it when the control unit emits the 4 final beeps preceding motor starting.
- The door immediately starts in closing mode and performs a slow speed opening/closing cycle that it will have to complete for the set-up to be correct.



At the end of the manoeuvre a prolonged BEEP signals the set-up is over.

IMPORTANT: during set-up don't place any obstacles in the door opening area and in the radar detection field; also, don't push the door manually.

• Functional testing

- Check automatic door operation by issuing a Start pulse through the PS1 button and checking leaf opening and closing.
- When dip 10 of S2 is OFF you can check through the buzzer the door thrust force during motion and verify its actual intensity. Through the TM4 potentiometer you can adjust the thrust power; take into account that a very short buzz at start only indicates proper power calibration, while multiple intermittent signals during the stroke indicate that thrust power is too low. To disable power signalling through the buzzer set dip 10 of S2 to ON once the testing is over.
- Set the desired control unit functions through dip switches S1 and S2 and adjust the door operation parameters through potentiometers TM1 to TM6.



IMPORTANT!

If any of the following parameters is changed, the initial SET-UP procedure will have to be repeated: leaf stroke, leaf weight, electric lock type.

To perform a new SET-UP follow the steps described at points a) to g) above.

14 - S1 DIP-SWITCH FUNCTIONS  S1

DIP 1 = ON	Bank function: the electric lock activates when the door is closed in both day and night lock programs.
DIP 1 = OFF	Standard function: the electric lock activates when the door is closed only in the night lock program.

DIP 2 = ON	Night lock program: the door closes and can be opened by inputs START and RADAR IN for an amount of time that varies between 10" and 120" (see P23 adjustment on EV-DSEL).
DIP 2 = OFF	Night lock program: the door closes immediately.

DIP 3 = ON	Battery operation: in case of mains failure in day programs the door opens and stays open. In night program the door can be opened through the Emergency input.
DIP 3 = OFF	Battery operation: in case of mains failure the door keeps working with all control inputs as long as the battery can supply power.

DIP 4 = ON	Battery monitoring: if the battery is low or damaged, the door opens and stays open in day programs.
DIP 4 = OFF	Battery monitoring: if the battery is low or damaged, the control unit emits a 1-second beep before opening the door. The beep is emitted for the first 10 manoeuvres in day programs since battery fault detection.

DIP 5 = ON	Running direction for EVOLUS-T door: for single leaf with rightward opening. Direction of travel for EVOLUS-T doors: for two mobile leaves with opening to the left.
DIP 5 = OFF	Running direction for EVOLUS door: for double leaf and single leaf with leftward opening. Direction of travel for EVOLUS-T doors: for four mobile leaves or two mobile leaves with opening to the right.

DIP 6 = ON	Device for the choice of the work program: EV-MSEL mechanical key selector.
DIP 6 = OFF	Device for the choice of the work program: EV-DSEL digital programmer.

Choice procedure of the manual free door program with the key mechanical selector		
DIP 7	DIP 8	
OFF	OFF	Standard mode of mechanical selector and manual free door off.
ON	OFF	Manual free door enabled for "exit only" position.
OFF	ON	Manual free door enabled for "night lock" position.
ON	ON	Manual free door enabled for "winter" position.

Electric lock type selection		
DIP 9	DIP 10	
OFF	OFF	FAIL SECURE EV-EBFSE (it locks the door the door if no power is supplied and the door is closed)
ON	OFF	FAIL SAFE EV-EBFSA (it frees the door if no power is supplied)
OFF	ON	BISTABLE EBBIS (if power is not supplied, the electric lock remains in its current position)

DIP 1 = ON	PRJ38 FT1/FR1 photocell: installed and working as safety device for closing.
DIP 1 = OFF	PRJ38 FT1/FR1 photocell: not installed.

DIP 2 = ON	PRJ38 FT2/FR2 photocell: installed and working as safety device for closing.
DIP 2 = OFF	PRJ38 FT2/FR2 photocell: not installed.

Operating mode of the third photocell pair FT3/FR3		
DIP 3	DIP 4	
OFF	OFF	PRJ38 FT2/FR2 photocell: not installed.
ON	OFF	PRJ38 FT3/FR3 photocell: nstalled and working as leaves breaking sensor.
OFF	ON	PRJ38 FT3/FR3 photocell: installed and working as safety device for closing.
ON	ON	PRJ38 FT3/FR3 photocell: installed and working as opening control.

DIP 5 = ON	Acceleration and braking ramp: radual for very narrow and light leaves.
DIP 5 = OFF	Acceleration and braking ramp: standard.


DIP 6 = ON	Test for safety sensor when opening: ACTIVE (for pre-arranged sensors only). See para. 23 "Sensor test".
DIP 6 = OFF	Test for safety sensor when opening: NOT ACTIVE.

DIP 7 = ON	Test for safety sensor when closing: ACTIVE (for pre-arranged sensors only). See para. 23 "Sensor test".
DIP 7 = OFF	Test for safety sensor when closing: NOT ACTIVE.

DIP 8 = ON	The activation of the safety sensor during opening stops motion until the obstacle is removed.
DIP 8 = OFF	The activation of the safety sensor during opening slows down motion until the opening stroke ends.

DIP 9 = ON	Motor management parameters: Evolus 150 or EVOLUS-T300
DIP 9 = OFF	Motor management parameters: Evolus 90 or EVOLUS-T200

DIP 10 = ON	It disables acoustic signalling through the buzzer related to thrust power restriction.
DIP 10 = OFF	It activates acoustic signalling through the buzzer related to thrust power restriction. See p. Functional testing Initial set-up.



TM1 potentiometer

Opening speed adjustment;
Increasing the value, the opening speed is increased too. Max. 0.7m. / sec. per leaf.

TM2 potentiometer

Closing speed adjustment;
Increasing the value, the closing speed is increased too. Max. 0.6m. / sec. per leaf.

TM3 potentiometer

Winter opening distance adjustment;
Increasing the value, the winter opening distance is increased too.

TM4 potentiometer

Thrust power restriction;
At maximum value, the maximum door thrust is obtained.

Tm5 potentiometer

Pausing time with open door;
Permitted values range from 0 to 20".


TM6 potentiometer

Adjustment of PRJ38 photocell sensitivity. Max range 6 metres.
See p. PRJ38 photocells.

17 - WORK PROGRAM SELECTION DEVICES

To select the EVOLUS automatic door work program you can use the mechanical key selector, or the display digital programmer.

17a) - MECHANICAL KEY SELECTOR



The **EV-MSEL** key mechanical selector permits to setup the work program of the automatic EVOLUS door. To enable its operation set dip 6 of S1 to ON (see paragraph 14).

ELECTRIC CONNECTIONS

TERMINAL 1 = connect to input 8 (INTERNAL RADAR) of the EVOLUS control unit;
 TERMINAL 2 = connect to input 11 (COMMON) of the EVOLUS control unit;
 TERMINAL 3 = connect to input 12 (AUX1 auxiliary) of the EVOLUS control unit;
 TERMINAL 4 = connect to input 15 (AUX2) of the EVOLUS control unit;

OPERATING MODE

Input and turn the key of the EV-MSEL selector to select the desired function among the 5 available functions:

-  **DOOR ALWAYS OPEN** = to keep the door open.
-  **WINTER OPENING** = to get a reduction of the opening space (anyway the START command opens the door completely).
-  **TWO-WAY TRAFFIC** = to open the door by means of all the control inputs
-  **OUTGOING TRAFFIC ONLY** = to exclude the incoming detection (EXTERNAL RADAR)
-  **NIGHT LOCK** = to keep the door closed, allowing its opening only by means of the EMERGENCY input

The key can be taken out of the selector when in any position in order to prevent the work program from undesired changes.

MANUAL FREE DOOR PROGRAM

The MANUAL FREE DOOR program can be selected by means of the key mechanical selector to disable the automatic mode of the door and to permit the manual movement of the leaves.

The Table shows how dips 7 and 8 of dip-switch S1 of the EVOLUS control unit can be setup for the management of the work program with the mechanical selector.

Choice procedure of the manual free door program with the key mechanical selector		
DIP7	DIP8	of dip switch S1 of the EVOLUS control unit
OFF	OFF	Standard mode of mechanical selector and manual free door off
ON	OFF	Manual free door enabled for "exit only" position
OFF	ON	Manual free door enabled for "night lock" position
ON	ON	Manual free door enabled for "winter" position


When switching from the MANUAL FREE DOOR program to an automatic program, the door starts working again with a slow opening.

Ivory ABS container, dimensions: L100xH80xD18mm

1) GENERAL INFORMATION

The digital programmer EV-DSEL can operate only together with the electronic control unit of the EVOLUS pedestrian automatic door and is used to set the automation work program. It also makes it possible to access a programming menu used to adjust the door operating parameters.

2) ELECTRIC CONNECTIONS



Connect the digital programmer EV-DSEL to the electronic control unit for the EVOLUS door using a 4 pole cable with a diameter of 0.5 mm.

- Terminal +13V** = connect to terminal +13V (1) of the EVOLUS control unit.
- Terminal -** = connect to terminal GND – (4) of the EVOLUS control unit.
- Terminal A** = connect to terminal A (2) della of the EVOLUS control unit.
- Terminal B** = connect to terminal B (3) of the EVOLUS control unit.

3) AUTOMATIC DOOR WORK PROGRAMS



By pushing the central button **YSETA** select the automatic door work mode. Each time a button is pressed, it switches from a work program to the next one.

The various available programs are described below.

<p>The door opens by activating any installed opening control.</p>  <p>①</p>	<p>The external radar is deactivated, all other opening controls remain active.</p>  <p>②</p>
<p>The internal radar is deactivated, all other opening controls remain active.</p>  <p>③</p>	<p>The door opens and remains open permanently.</p>  <p>④</p>

The door is closed and the radars and Start are not active. The door may only be opened with the Emergency opening button.



⑤

The door's automatic mode is deactivated and the leaves can be moved manually.



⑥

REDUCED OPENING



⑦

Press the button  to reduce the passage opening.

The symbol  on the display indicates that the function is on. To turn off the reduced opening function, press the same button again.

4) PASSWORD



⑧

To prevent the set function from being modified, a password can be entered that must be input every time the digital programmer is used.

WARNING!

When enabling the password, be careful not to forget the access combination.

To enable the password, follow the steps described below. From the work program display, press the  button for 8 seconds.

The programming menu will appear on the display.

Press the button **F1** until accessing CODE, which corresponds to the password section. Briefly press the ENTER  button to access password selection.



⑨

The current password is requested.



⑩



⑪

Enter the default password provided by LABEL with all digital programmers.

The default LABEL password is composed of 5 characters and is A-A-A-A-A.

Press the button in correspondence of the letter "A" and an asterisk will appear on the display in the field for the first letter.

Press the button in correspondence of the letter "A" a second time, and an asterisk will appear on the display in the field for the second letter.

12



Press the button in correspondence of the letter "A" a third time, and an asterisk will appear on the display in the field for the third letter.

13



Press the button in correspondence of the letter "A" a fourth time, and an asterisk will appear on the display in the field for the fourth letter.

14



Press the button in correspondence of the letter "A" a fifth time and a screen will appear on the display that asks whether to enable the password "ON" or disable the password "OFF" (if the button in correspondence of OFF is pressed, you will exit password selection and return to the programming menu)

15



If the ON button is pressed, a screen will appear on the display where the new password is requested. Now enter the desired password, selecting a combination of 5 characters from the letters A-B-C-D. To select the letters, press the button in correspondence of the letter itself.

16



After entering the password the first time, the combination must be repeated a second time. Enter the previous password again.

17



If the entered password is correct, the message "PASSWORD OK!!" will appear on the display.

18



The system will now automatically return to the main programming menu. Press the ENTER  button for 3 seconds to exit the programming menu and return to the main work programming selection screen.

19





20

At this point, the password will be requested each time that the work program must be changed. Simply enter the selected combination to use the digital programmer. To change the password or disable it, repeat the previous operations.

5) LANGUAGE SELECTION

It is possible to select the preferred language for viewing the programs and functions described on the display . To select the language, follow the steps described below.



21


From the work program display, press the **SET** button for 8 seconds.

The programming menu will appear on the display.



22

Press the **F1** button until accessing the  section, which corresponds to language selection.



23

Briefly press the ENTER **SET** button to access language selection.

Use the **F2** or  button to select the desired language. The arrow to the left shows the preselected language.

Briefly press the EXIT **SET** button to return to the main programming menu.

Press the ENTER **SET** button for 3 seconds to exit the programming menu and return to the main work programming selection screen.

6) FUNCTIONS and SETTINGS

The digital programmer can be used to set all dip switch and potentiometer functions to select the operating mode of the automatic door. To carry out the settings, follow the steps described below.

24



From the work program display, press the button for 8 seconds.

The programming menu will appear on the display (see fig.24, to the side).

25



Press the **F1** button until the  section that corresponds to the functions and settings is displayed and briefly press the ENTER  button to access it.

WARNING!!


The functions F01 to F20 correspond to two dip switches with 10 microswitches, S1 and S2, on the electronic control unit. The potentiometers P01 - P05 correspond to the potentiometers TM1 - TM5 on the electric control unit.

It is possible to select if these parameters should be set directly from the electronic control unit or from the digital programmer. The latter solution is extremely helpful if the automatism already has the casing assembled.

To carry out the settings for parameters F01 - F20 and P01 - P05 from the digital programmer, go to function F21 and set it to ON.

Parameters F22 - F40 relative to the dip switches and P06 - P35 relative to the potentiometers are set from the digital programmer independently of the status of the F21 function.

26



To set the functions relative to the dip switches, briefly press the F01 **F2** button (see paragraph 6a).

To carry out the settings relative to the potentiometers, briefly press the P01  button (see paragraph 6b).


6a) How to set the FUNCTIONS of the DIP SWITCHES

The number of the dip switch being set (F01, F02, F03, etc...) is indicated on the left side of the display, in the center. The status of the dip switch being set (OFF, ON) is indicated on the right side of the display, in the center.

To change the status of a dip switch, press the ON **F3** button to set the dip switch to ON .

To return the status of the dip switch to OFF, press the OFF button **F1** .

27



28



29



To advance the number of the dip switch to be set briefly press the **F2** button.
By holding down the button, the functions will advance quickly.

To return to the previous dip switch briefly press the  button.
By holding down the button, the selection will go back quickly

The available functions arrive up to F40 and the main screen on the display describes the work mode relative to each function.
For a more detailed description of the operation of each function, consult paragraph 19.
To exit the section relative to FUNCTIONS and SETTINGS, briefly press the EXIT  button to return to the main programming menu screen.

Press the ENTER  button for 3 seconds to exit the programming menu and return to the main work programming selection screen.

6b) How to carry out POTENTIOMETER SETTINGS

The number of the potentiometer being set (P01, P02, P03, etc...) is indicated on the left side of the display, in the center.

The percentage scale of the set value is indicated on the right side of the display, at the center.

30




To decrease the value of the potentiometer, press the **F1** button.
The percentage can arrive up to a value of 0.

31




To increase the value of the potentiometer, press the **F3** button.
The percentage can arrive up to a value of 100%.

32



To advance the number of the potentiometer to be set briefly press the  button.
By holding down the button, the potentiometers will advance quickly.
To return to the previous potentiometer briefly press the **F2** button.
By holding down the button, the selection will go back quickly.

33



The available potentiometers arrive up to P35 and the main display screen shows a description of the type of parameter to set.
For a more detailed description of each individual parameter, consult paragraph 20.

To exit the section relative to FUNCTIONS and SETTINGS, briefly press the EXIT  button to return to the main programming menu screen.

Press the ENTER  button for 3 seconds to exit the programming menu and return to the main work programming selection screen.

7) INITIAL SET-UP from the digital programmer

The set-up phase for the automatic door can be carried out from the digital programmer. Follow the steps described below.

From the work program display, press the **SET** button for 8 seconds.

The programming menu will appear on the display.

The **!** section that corresponds to initial set-up will appear immediately. Briefly press the **ENTER** button to access it.



34

The first requested setting "S01" concerns the running direction: select OFF with the **F1** button in the case of a double leaf or single leaf door with leftward opening, or select ON with the **F3** button with a single leaf with rightward opening.



35

Press the ***** button to go to the second setting required, "S02", relative to the other electric lock: select OFF with the **F1** button with a FAIL SECURE electric lock or ON with the **F3** button with a FAIL SAFE type.




36

Press the ***** button to go to the third setting required, "S03", relative to the automatism module: select OFF with the **F1** button for an EVOLUS 90 model or ON with the **F3** button for an VOLUS 150 model.



37



38

Press the ***** button. At this point, the automatic door is ready for the set-up manoeuvre. Press the OK button ***** to start the set-up cycle. The digital programmer exits the set-up section and displays the main work program selection screen.


8) Input status DIAGNOSTICS

Press the **F2** button for 8 seconds on the main work program selection screen.



39

A screen will appear on the display that shows the symbols for all EVOLUS control unit inputs with the relative terminal number. If an input is engaged, the relative warning light will turn on and an arrow will appear next to the symbol.



40

To exit the input symbol screen and return to the main work program selection screen, briefly press the **EXIT** button.

9) POWER WARNING LIGHT DISPLAY

41



If the symbol  appears in the upper left corner of the display, this means that the network power supply voltage is present and the battery, if present, is connected correctly and is charging.

42



If the symbol  appears in the upper left corner of the display, this means that the network power supply voltage is not present and the door is operated using the emergency battery that is in working order.

43



If the symbol  appears in the upper left corner of the display, this means that the network power supply voltage is not present and the emergency battery is almost discharged. The same symbol indicates that the battery is not working, even if the network power supply voltage is present.

18 - "UR1" MODULE

The UR1 module is an optional interface board, designed to manage the functions described below.

It is equipped with a no-voltage contact relay output (terminals 1-2) that can be of N.O. or N.C. type (depending on the position of the J1 jumper) and of a signal output "-" of OPEN COLLECTOR type.

The UR1 module must be coupled to the OUT3 connector of the EVOLUS control unit.

- **HEAT BLADE**

- **FUNCTION F35 = OFF on digital programmer unit EV-DSEL**

Use the no-voltage contact on terminals 1 and 2 of the UR1 module to control an air blade, which is a device that generates a cold or heated air flow to separate the external temperature from the internal temperature.

The output is active when the door is moving or open, whereas it deactivates when the door is closed.

- **DOOR OPEN WARNING LIGHT**

- **FUNCTION F35 = OFF on digital programmer unit EV-DSEL**

Use the no-voltage contact on terminals 1 and 2 of the UR1 module to supply power to a door status warning light:

the output is active when the door is in motion or open, while it disables when the door is closed.

- **WARNING GONG FOR DOOR IN OPERATION**


- **FUNCTION F35 = ON**

Refer to paragraph 22 for a detailed description of the GONG operation.

- **INTERLOCKING SYSTEM BETWEEN TWO AUTOMATIC DOORS**

FUNCTION F22 = ON (when this function is ON it automatically excludes the other functions associated with F35).

Refer to paragraph 21 for a detailed description of the interlocking system.



19) DESCRIPTION OF FUNCTIONS SELECTABLE FROM EV-DSEL DIGITAL PROGRAMMER (F01 to F40)

For information about how to access FUNCTIONS and ADJUSTMENTS refer to paragraph 17b of this manual and then refer to sub-sections 6) and 6a) about how to set the functions of the dip-switches.

Functions F01 to F10 correspond to dials 1 to 10 of dip-switch S1 which are described in paragraph 14 of this manual.

Functions F11 to F20 correspond to dials 1 to 10 of dip-switch 20 which are described in paragraph 15 of this manual.

The following describes functions F21 to F40.

F21

Function F21 establishes how to adjust functions F01 to F20 and potentiometers P01 to P05.

F21 OFF = adjustments only possible from electronic control unit; the key symbol in the lower left part of the display for parameters F01 to F20 or for P01 to P05 indicates that F21 is OFF (refer to fig.A); if you attempt to modify the status of a parameter from the EV-DSEL digital programmer for F01 to F20 or P01 to P05 the display will advise you to set F21 to ON (refer to fig.B).

F21 ON = adjustments only possible from electronic control unit EV-DSEL; if the key symbol is not visualised at the lower part of the display for parameters F01 to F20 or P01 to P05 this means that F21 is ON (refer to fig.C).




Fig.A



Fig.B




Fig.C

F22

Function F22 enables the interlocking between two doors which must be opened alternatively.

For a detailed description of the interlocking function refer to paragraph 21.

F22 OFF = interlocking function **OFF**.

F22 ON = interlocking function **ON**.



F23

Function F23 is only used when the interlocking function is ON (F22 = ON) and is used to establish which one of the two doors has priority in the case when both doors are opened at the same time.

For a detailed description of the interlocking function refer to paragraph 21.

F23 OFF = The door opens with a 0.5 secs delay with respect to the open command.

F23 ON = The door opens immediately upon receipt of the open command.



F24

Function F24 is only used if the interlocking function is ON (F22 = ON) and is used to store the presence detected by the radar sensors on the door which is closed, and to open this as soon as the other door is fully closed.

For a detailed description of the interlocking function refer to paragraph 21.

F24 OFF = Store presence sensor **OFF**.

F24 ON = Store presence sensor **ON**.



F25

Function 25 disabled; keep in OFF.



F26

Function 26 disables the step-by-step operating mode and excludes the automatic re-closing of the door.

The control inputs enabled for step-by-step operation are START and EMERGENCY.

The operation cycle is as follows:

the first control impulse opens the door, the second impulse closes the door.

F26 OFF = step-by-step program **OFF**.

F26 ON = step-by-step program **ON**.



F27

Function 27 operates the electric lock with doors closed in the EXIT ONLY program.

F27 OFF = electric lock **OFF** with doors closed in EXIT ONLY.

F27 ON = electric lock **ON** with doors closed in EXIT ONLY.



F28

Function 28 enables the continuous opening and closing cycle, which is useful when it is required to continuously test the operation of the door. Start the first opening with the START command

F28 OFF = cyclic function **OFF**.

F28 ON = cyclic function **ON**.




F29

Function 29 enables PUSH & GO, to allow the door to be opened by manually moving it a few cms.

F29 OFF = PUSH & GO **OFF**.

F29 ON = PUSH & GO **ON**.




F30

Function 30 determines the logic state of the emergency input between terminals 5 and 7.

F30 OFF = emergency input N.C. contact (normally closed); normal condition.

F30 ON = emergency input N.O. contact (normally open).



F31

Function 31 enables the fire door operating mode, and it is only possible when the interlocking function is OFF (F22 OFF).

F31 OFF = fire door function **OFF**.

F31 ON = fire door function **ON**.

The following is a description of the operating mode.

By connecting a smoke detector with a N.C. contact to the STOP/I input (between terminals 11-14) the door is forced to the closed position at slow speed after the smoke detector is enabled. During this operation all the control inputs are inactive.

When the door is closed once again due to the smoke detector being activated, the door can be only be re-opened by means of the Emergency input, which acts in a pulse mode if the smoke detector no longer detects the alarm condition. and acts in 'man present' mode if the smoke detector continues to detect the presence of smoke.




F32

Function 32 enables an automatic increase of the time pause delay with door open if the door is not able to be closed due to the high number of people. The pause time delay is reset to the set value when the door is fully closed.

F32 OFF = increase pause time delay **OFF**.

F32 ON = increase pause time delay **ON**.




F33

Function 33 enables the transition from winter opening to total opening after one minute if it is not possible to close the door due to the high number of people. The winter opening distance is reset the first time the door is fully closed.

F33 OFF = transition from winter opening to total opening **OFF**.

F33 ON = transition from winter opening to total opening **ON**.



F34

Function 34 enables the immediate re-closing of the door, without completing the opening and the pause delay time, from the moment when the safety photocells and radar sensors are cleared.

F34 OFF = immediate re-closing **OFF**.

F34 ON = immediate re-closing **ON**.



F35

Function 35 determines the operating mode for output OUT 3 (connector J7), in which the interface module UR1 must be inserted (refer to paragraph 18).

*This function is **not** enabled if the interlocking function is ON (F22 = ON).*

F35 OFF = output OUT 3 configured as HEAT BLADE or DOOR OPEN INDICATION LAMP (refer to paragraph 18); the output is enabled with the door open or door moving, and is disabled with the door closed.

F35 ON = output OUT 3 configured as warning GONG for door crossing indication. For a detailed description of the GONG function refer to paragraph 22.



F36

Function 36 disabled; keep in OFF.



F37

Function 37 disabled; keep in OFF.



F38

Function 38 disabled; keep in OFF.



F39

Function 39 disabled; keep in OFF.



F40

Function F40 is used to reset potentiometers P06 to P20 to the default value, which may have been modified by the operator during the initial set-up phase.

To cancel these changes and return the potentiometers to the default values set function F40 to ON and the digital programmer will automatically reset the values to the default settings, and the FUNCTIONS and ADJUSTMENTS menu will appear.



20) DESCRIPTION OF POTENTIOMETERS ADJUSTABLE FROM EV-DSEL DIGITAL PROGRAMMER (P01 to P35)

For information about how to access FUNCTIONS and ADJUSTMENTS refer to paragraph 17b of this manual and then refer to sub-sections 6) and 6b) about how to adjust the potentiometers.

Potentiometers P01 to P05 correspond to potentiometers TM1 to TM5 in the electronic control unit which are described in paragraph 16 of this manual.

The following is a description of potentiometers P06 to P35.

P06 = Obstacle perception

Potentiometer P06 sets the intervention sensitivity in the case of banging against an obstacle.

By decreasing the value the sensitivity is increased.

If the door bangs against an obstacle it stops and inverts the direction of movement.

The subsequent manoeuvre takes place at reduced speed to check whether the obstacle is still present.



P07 = Acceleration ramp when opening

Potentiometer P07 sets the acceleration thrust of the door when opening to reach the opening speed set by P01 from the stopped position.

By increasing the value a quicker acceleration is achieved.



P08 = Acceleration ramp when closing

Potentiometer P08 sets the acceleration thrust of the door when closing to reach the closing speed set by P02 from the stopped position.

By increasing the value a quicker acceleration is achieved.



P09 = Braking ramp when opening

Potentiometer P09 sets the braking intensity of the door at the end of the opening cycle.

By increasing the value a quicker braking is achieved



P10 = Braking ramp when closing

Potentiometer P10 sets the braking intensity of the door at the end of the closing cycle.

By increasing the value a quicker braking is achieved



P11 = Deceleration distance when closing

Potentiometer P11 sets the deceleration start distance at the end of the opening cycle. By increasing this value a greater deceleration distance is obtained.




P12 = Deceleration distance when closing

Potentiometer P12 sets the deceleration start distance at the end of the closing cycle. By increasing this value a greater deceleration distance is obtained.



P13 = Thrust power at the end of the closing cycle

Potentiometer P13 sets the thrust power during the last stages of the closing cycle, which is useful to facilitate the complete closing of the wing against the final ledge. By increasing this value the thrust power is increased.



P14 = Thrust power at the end of the closing cycle

Potentiometer P14 sets the duration of the thrust during the last stages of the closing cycle, which is useful to facilitate the complete closing of the wing against the final ledge. By increasing the value the thrust duration time is increased.




P15 = Holding tension with door closed

Potentiometer P15 sets the holding tension to the motor when the door is closed, which is useful to keep the wings against the final ledge. By increasing the value the motor holding tension is increased.



P16 = Wind stop intensity with door closed

Potentiometer P16 sets the counter force of the motor during closing in the case when forcing the door to the open position. By increasing the value the counter force is increased.



P17 = Braking power when closing after inversion of door movement

Potentiometer P17 sets the braking power of the wing during the closing phase, prior to inverting the direction of travel to open the door. By increasing the value a quicker braking is achieved




P18 = Distance from mechanical limit switch when opening

Potentiometer P18 allows you to change the distance between the end of travel when opening the wing and the mechanical limit switch, with respect to the value preset automatically during set-up. By increasing the value the distance is increased.



P19 = Reduced speed

Potentiometer P19 sets the reduced speed of the wing during movement after banging against an obstacle. In fact, if during movement the wing bangs against an obstacle it will invert its direction of travel, but the next time it moves in the same direction it will move at a reduced speed with respect to normal speed to limit the force in the case of further impact when the obstacle is still present. By increasing the value the reduced speed is increased; max. 0.2m./sec. per wing.



P20 = Potentiometer disabled



P21 = Waiting time between 2 consecutive warning gongs for door crossing

For a detailed description of the GONG function refer to paragraph 22.




P22 = Start delay when opening with respect to activation of electric lock

Potentiometer P22 sets the start delay when opening the door with respect to activation of the electric lock. At the lower limit value the wing starts immediately when the electric lock is activated, at the maximum limit value the wing starts with a delay of approx. 0.8 seconds.



P23 = Internal Radar enable time and Start Night time lock program

Potentiometer P23 sets the time for which the internal Radar and Start inputs are enabled to open the door after the Night Lock mode has been set by the program selector switch. At the minimum value the inputs stay active for 10 seconds after the Night Lock program has been set, while they stay active for two minutes at the maximum value.



P24 = Interlocking disable time in the case of a high number of people

Function P24 sets the time after which the interlocking feature is automatically excluded if one of the two doors is not able to close due to the high number of people. Consequently, after the time has expired, and if the interlocking input is activated for the door which is closed and the radar sensor detects the presence of people, the door opens allowing the people to move through the area. At the minimum value 00% the function is not enabled and the interlocking is always ON. At 01% of the value the interlocking disable time and consequent opening of the door will be set at 10 seconds. At the mean value of 50% the time will set at one minute. At the maximum value of 100% the time will be set at 2 minutes. For a detailed description of the interlocking function refer to paragraph 21.




P25, P26, P27, P28, P29, P30, P31, P32, P33, P34, P35 = Potentiometers OFF

21) INTERLOCKING SYSTEM BETWEEN TWO AUTOMATIC DOORS

The interlock system is used when two automatic doors must open one at a time, so they must not move together. For the electrical connection between the automation electronic control units a UR1 module is required (optional) for each control unit. Insert the UR1 module on connector J7-OUT 3 of the electronic control unit. It will be necessary to install the EV-DSEL digital programmer to set the functions and to select the work program for the doors for each Evolus operator. You are not allowed to use the EV-MSEL mechanical selector.

21.1) ELECTRIC CONNECTION

INTERLOCK SYSTEM DIAGRAM *EVOLUS*



**The dotted line of the ON/OFF switch connected to the AUX/1 input is used to disable the interlock operation (connection not essential for the system operation).
 Switch OFF (contact open): interlock ON
 Switch ON (contact closed): interlock OFF.**

The diagram above illustrates the electrical connection between the two Evolus control units controlling the two automatic doors in the interlocking configuration.

- Terminal 11 (COM) of control unit A must be connected to terminal 2 of its own UR1 module.
- Terminal 1 of the UR1 module of control unit A must be connected to terminal 14 (STOP/I) of control unit B.
- Terminal 11 (COM) of control unit B must be connected to terminal 2 of its own UR1 module.
- Terminal 1 of the UR1 module of control unit B must be connected to terminal 14 (STOP/I) of control unit A.
- Both terminals 7 (COM) of each control unit must be connected together.
- By connecting a switch (SWITCH ON/OFF) between the terminals 7 (COM) and 12 (AUX1) of both control units, it is possible to cut off the interlock function with a closed contact of the switch and to re-enable the interlock function with open contact. The use of this switch is optional, it is used only if there is the need to cut off temporarily the interlock detection and to allow the free passage between the two doors.

21.2) INTERLOCK FUNCTION ACTIVATION

1. Set dip **6** of dip-switch **S1** to **OFF** for both control units, to enable the work program to be selected from the EV-DSEL digital programmer.
2. Set function **F22 ON** for both control units by means of the EV-DSEL digital programmer, so as to enable the interlocking function.
3. To establish which of the two doors has priority when both doors are opened at the same time operate function F23 of the EV-DSEL digital programmer:
F23 OFF = The door opens with a 0.5 secs delay with respect to the open command.
F23 ON = The door opens immediately upon receipt of the open command.
For example, if you require control unit A to open the door in the case of two commands at the same time, set F23 ON in control unit A and F23 OFF in control unit B.

21.3) WORKING METHOD OF INTERLOCKING FUNCTION

With the doors closed, when one of the two Automation units receives an opening command, it will attempt to open the door, while the second door will remain closed. The second door can only open when the first door has been fully closed.

The START input (terminal 10) may be used as a common connection for both control units, by connecting a presence sensor (radar, pressure sensitive mat, etc.) positioned between the two doors.

The functionality of the Start input feature is as follows:

during the closing phase and for 5 seconds after the end of the closing phase the detection on the Start input is ignored to allow the moving door to finish the closing operation and to allow, immediately afterwards, the other door to be opened.

When required, it is possible to open the door which has remained closed by activating the Emergency input (terminal 5).

If a switch (switch ON/OFF) has been installed at AUX1 input (terminal 12) it is possible to exclude the interlocking function and to allow the free passage between the two doors;

when the switch is ON the interlocking function is OFF;

when the switch is OFF the interlocking function is ON

To store the presence of someone in front of the radar sensor of the door which is closed and to open this door as soon as the other door has completely closed, even if the presence is not detected by the radar, set function **F24 to ON** at the EV-DSEL digital programmer.

To automatically exclude the interlocking function when one of the two doors is not able to be closed due to the high number of people, operate potentiometer F24 at the EV-DSEL digital programmer.

For further information refer to paragraph 20 under item:


P24 = *Interlocking disable time in the case of a high number of people.*

22) DOOR CROSSING WARNING GONG

The GONG function is a warning when entering into an area generated by the safety photocells (intended as external photocell connected to terminal 6, or photocell Label PRJ38) during crossing of the automatic door.

To enable the GONG function you will require an EV-DSEL digital programmer and UR1 module.

GONG FUNCTION DIAGRAM



Perform the following operations to activate the GONG function:

- Use module UR1 (refer to paragraph 18) and insert this on connector J7-OUT 3 of the EVOLUS control unit.
- Select the N.O contact between terminals 1 and 2 of the UR1 module by means of jumper J1.
- Connect the entry warning buzzer (GONG) by connecting the power supply to the voltage-free contact at terminals 1 and 2 of the UR1 module. The diagram above illustrates the electrical connection in the case a 12 Vdc supply is used, by taking the power supply directly from terminals 17-18 of the EVOLUS control unit.

WARNING!

To stop the unwanted operation of the GONG during the set-up procedure of the control unit, it is recommended to provide power supply to the buzzer only at the end of set-up after having enabled the GONG function as described below.

- To activate the GONG function use the EV-DSEL digital programmer and set **F35 ON**;
at this point each time that the safety photocells are operated when closing the door the GONG will sound for 2 seconds.
- To change the waiting time from when the GONG buzzer is activated to the next time it is activated, by operation of the safety photocells, operate potentiometer **P21** on the EV-DSEL digital programmer.

This waiting time is used to prevent the buzzer from sounding continuously in the case of the passage of a high number of people. This time is reset when the door is completely closed.

The table below provides some information about the waiting times according to the set value of P21.

P21= Waiting time between 2 consecutive warning gongs for door crossing	
P21 at 00%	GONG OFF
P21 at 01% (default)	Immediate activation at each passage
P21 at 02%	1 second interval
P21 at 05%	5 seconds interval
P21 at 10%	15 seconds interval
P21 at 15%	30 seconds interval
P21 at 20%	45 seconds interval
P21 at 25%	60 seconds interval
P21 at 50%	120 seconds interval
P21 at 100%	255 seconds interval

- Now the GONG function is definitely ON.
By crossing the automatic door and by engaging the safety photocell when closing the audible indication of the GONG will sound for 2 seconds, the GONG will then be inhibited for the waiting time set previously with P21.
Once the waiting time has expired, the GONG will be activated again for 2 seconds if the door crosses by engaging the safety photocell when closing.

WARNING!

If the interlocking function is used (F22 ON), the gong function will be automatically set to OFF.


23) SENSOR TEST

The Evolus operator control unit is pre-arranged to monitor the correct operation of the safety sensors.

WARNING!!

Only activate the TEST function when sensors pre-arranged for monitoring are used (i.e. ACTIV 8 ONE ON present in the Label List).

CONNECTION DIAGRAM OF SENSORS WITH TEST FUNCTION



The diagram illustrates the connection on the operator of two sensors with twin outputs and monitoring test to detect movement (radar) and presence (safety photocell).

- You can carry out the functional test on safety sensors connected to the safety photocell input during closing (terminal 6, see figure above). To activate the test function set **dip 7** on switch **S2** to **ON**.

By means of jumper J12 select if the test should be positive or negative:

J12 to P = positive signal (suitable for ACTIV8 ONE sensor ON);

J12 to N = negative signal.

The choice depends on the type of sensor, therefore please consult the operating instructions for the sensor.

Verification of the correct operation of the sensor takes place at the start of each movement of the door. If the sensor does not respond correctly to the safety test, the control unit will give off a bip sound and the door will close slowly.

- You can carry out the test on safety sensors connected also to the side safety sensor input during opening (terminal 13). To activate the test function set **dip 6** on switch **S2** to **ON**.

By means of jumper J12 select if the test should be positive or negative:

J12 to P = positive signal;

J12 to N = negative signal.

The choice depends on the type of sensor, therefore please consult the operating instructions for the sensor.

Verification of the correct operation of the sensor takes place at the start of each movement of the door. If the sensor does not respond correctly to the safety test, the control unit will give off a bip sound and the door will open slowly.

24) MEANING OF BUZZER WARNING SIGNALS (BIPs)

Short series of bips at POWER-UP = control unit has not been set-up.

1 prolonged BIP (5") = initial set-up has terminated.

1 long BIP (1") = indication of faulty battery and next opening.

Series of short bips (with dip 10 on S2 OFF) during movement = insufficient thrust (check the adjustment of potentiometer TM4).

5 BIPs at intervals of 0,5" secs. - 1 BIP = ENCODER or MOTOR NON OPERATIONAL

4 BIPs = intervention on STOP input (terminal 14).

4 BIPs = PHOTOCELL 3 (PRJ38) intervention as leaf breaking sensor.

1,2,3 BIPs = auto-diagnostics failed for photocells 1,2,3 respectively (indication is given at the start of each closing maneuver).

1 BIP = sensor test failed on safety photocell input during closing, or side safety sensor input during opening.

25 – PROBLEMS, CAUSES AND REMEDIES

CAUTION! It is always recommended to have the digital programmer EV-DSEL available at each intervention on the automatic door (even if the mechanical selector EV-MSEL is physically installed), to be able to perform the diagnostics on the input status and to gain access to all those functions and adjustments which can only be operated by use of the digital programmer EV-DSEL.

PROBLEM	LIKELY CAUSE	SOLUTION
The control unit gives off a short series of BIPs at POWER-UP and the door does not move.	The initial SET-UP procedure has not been carried out on the control unit.	Perform the initial SET-UP procedure as described in paragraph 13.
During the SET-UP procedure the motor is not able to move freely and the control unit gives off short warning bips.	Any friction of the fixture could impede the movement of the door.	Properly arrange the door fixture and check that it moves correctly.
During the initial SET-UP procedure the motor does not move.	The control and safety inputs are incorrectly connected..	Check the electrical connections on the safety control input circuits.
	The control and safety inputs are engaged.	Remove any obstacles from the radar or photocell detection fields.
Incorrect direction of movement of the door.	Incorrect setting of DIP5 on dip-switch S1.	Correctly set the setting of DIP5 on dip-switch S1 and repeat the SET-UP procedure.
The control unit does not respond to the variation of dip switches S1 and S2 or potentiometers TM1 to TM5.	Function F21 is set to ON (adjustment only possible by the use of digital programmer EV-DSEL).	Perform the required changes by means of the digital programmer EV-DSEL, or set function F21 to OFF and make the adjustments from the electronic control unit.
The door gives off a bip before opening.	Battery is faulty or disconnected.	Check the correct operation and connection of the battery operated anti-panic system EV-BAT1.
The door opens but it doesn't close back.	Radar or photocell detect a presence.	Check that the radar or photocells are not engaged or faulty.
	DIP 4 on S1 is set to ON and the battery is disconnected or faulty.	Check the correct operation and connection of the battery operated anti-panic device.
The door stops during the stroke and inverts the running direction. During the next operation motion is slower.	The door detects an obstacle along its stroke.	Identify the obstacle and remove it.
	There is friction of the door fixture which is seen as an obstacle.	Properly arrange the door fixture by eventually increasing the value of P6 "Obstacle perception" by means of digital programmer EV-DSEL.
The door moves with difficulty in short jerks.	Insufficient thrust power provided by motor.	Increase the value of potentiometer TM4 (thrust power).
The door opens for a short time, it then stops and gives off 6 BIPs.	Encoder connector is disconnected or encoder is damaged.	Check that the 4-pole connector of the encoder is inserted and LEDs E1 and E2 are lit on the control unit by manually moving the door.
PRJ38 photocells are connected but the control unit does not detect them, or indicates auto-diagnostics failure by means of the control unit bip.	Dips 1,2,3 and 4 on dip-switch S2 are not selected correctly.	Set DIPs DIP 1,2,3 and 4 on dip-switch S2 according to the number of PRJ38 photocells used.
	Electrical connection of the photocell PRJ38 capsule is incorrect.	Check the electrical connection of photocell PRJ38 (correspondence of cable colors with relevant terminals).
Battery operated anti-panic EV-BAT1 is connected, but the door does not open automatically when the 230V mains supply fails.	DIP 3 on S1 is OFF, therefore the opening is not automatic, but must be controlled through an open input command.	Set DIP 3 on S1 to ON so as to obtain automatic opening of the door when there is no 230V power supply.
The control unit will give off a BIP sound and the door opens slowly.	DIP 6 on S2 is ON and the test on the safety photocell during opening has failed.	If the closing safety sensor is not pre-arranged for the TEST function, set DIP 6 on S2 to OFF. However if the opening safety sensor is pre-arranged for the TEST function, this could be faulty or connected incorrectly.
The control unit will give off a BIP sound and the door closes slowly.	DIP 7 on S2 is ON and the test on the safety photocell during closing has failed.	If the closing safety sensor is not pre-arranged for the TEST function, set DIP 7 on S2 to OFF. However if the closing safety sensor is pre-arranged for the TEST function, this could be faulty or connected incorrectly.
Incorrect operation of electric lock.	Incorrect setting of dip switches according to the type of electric lock used.	Set dips 9 to 10 on S1 correctly according to the type of electric lock used and repeat the initial SET-UP procedure.



LABEL S.p.A.
Via Ilariuzzi, 17/A - S. Pancrazio Pse - 43126 - PARMA - Italy
Tel. (+39) 0521/6752 - Fax (+39) 0521/675222
www.labelsipa.it

DECLARATION OF CONFORMITY



Manufacturer: Label S.p.A.

Address: via Ilariuzzi 17/A - 43126 San Pancrazio Parmense, PARMA - ITALY

Declare that: the sliding door operator EVOLUS - EVOLUS-T

- ◆ is built for being incorporated in a machine or for being assembled with other devices in order to build a machine included in the Machinery Directive 98/37/CE
- ◆ complies to the safety essential requisites of the following directives:
 - Low Voltage Directive 2006/95/CE
 - Electromagnetic Compatibility Directive 2004/108/CE

Besides, we declare that its use is not allowed until the machine, of which the product is integral part, is not declared compliant with the Machinery Directive.

Parma, 12/06/2009

The President
Bruno Baron Toaldo


Bruno Baron Toaldo

EVOLUTION



LABEL S.p.A.
Via U. Ilariuzzi, 17/A - S.Pancrazio Pse - 43126 - Parma
Tel. (+39) 0521/6752 - Fax (+39) 0521/675222
www.labelsa.com



AZIENDA CERTIFICATA
SISTEMA QUALITA'
UNI EN ISO 9001:2000